

Do not use your product if these steps fail. Call 1-800-537-4129 or visit www.karcherresidential.com.

⚠ WARNING – Risk of Electrocutation –

- Inspect cord before using – Do not use if cord is damaged.
- Keep all connections dry and off the ground.
- Do not touch plug with wet hands.
- Do not use extension cord with this product.
- Connect to individual branch circuit only.



1. Plug the Ground Fault Circuit Interrupter (GFCI) into a working outlet.



2. Locate "RESET" button.

Do not use your product if these steps fail. Call 1-800-537-4129 or visit www.karcherresidential.com.



3. Press "RESET" button.




4. Locate "TEST" button.




5. Press "TEST" button.

Do not use your product if these steps fail. Call 1-800-537-4129 or visit www.karcherresidential.com.



6. Red indicator on “RESET” button should appear.

Inset: Red indicator should be VISIBLE inside the button housing from the side or the top



7. Press “RESET” button.

You have successfully tested the GFCI function.
You are ready to begin using the product.

This product is provided with a ground fault circuit interrupter (GFCI) built into the plug of the power-supply cord. This device provides additional protection from the risk of electric shock. Should replacement of the plug or cord become necessary, use only identical replacement parts that include GFCI protection. Contact Kärcher Customer Care.

Still have questions? Visit our website at www.karcherresidential.com or call our customer care line at 1-800-537-4129. We thank you for your purchase and hope you enjoy your Kärcher product.